

Chapter 4 Part B: Fuel and exhaust systems – diesel engines


Contents

	Section number
Accelerator pedal/position sensor – removal and refitting	4
Air cleaner assembly – removal and refitting	3
Exhaust manifold and turbocharger – removal and refitting	17
Exhaust system – general information, removal and refitting	18
Fuel gauge sender unit – removal and refitting	6
Fuel injectors – removal and refitting	12
Fuel rail – removal and refitting	11
Fuel supply pump – removal and refitting	7
Fuel system – priming and bleeding	5
Fuel tank – removal and refitting	8


	Section number
General information and precautions	1
High-pressure diesel injection system – special information	2
High-pressure fuel pump – removal and refitting	10
Injection system electrical components – removal and refitting	9
Intake manifold – removal and refitting	13
Intake manifold changeover flap actuator drive – removal and refitting	14
Intercooler – removal and refitting	15
Turbocharger – description and precautions	16

Degrees of difficulty


Easy, suitable for
novice with little
experience




Fairly easy, suitable
for beginner with
some experience




Fairly difficult,
suitable for competent
DIY mechanic



Difficult, suitable
for experienced DIY
mechanic



Very difficult,
suitable for expert
DIY or professional



Specifications

System type

All engines

Bosch EDC 16C9 high-pressure direct injection 'common-rail' system,
electronically controlled

Fuel system data

Firing order

Fuel system operating pressure

Idle speed

Maximum speed

High-pressure fuel pump:

Type

Fuel supply pump:

Type

Delivery pressure

Injectors:

Type

Injection holes (per injector)

Resistance

1-3-4-2 (No 1 at timing belt end of engine)
1600 bar at 2200 rpm
Controlled by ECM
Controlled by ECM

Bosch CP1H

Electric, mounted in fuel tank
3.3 bar (maximum)

Bosch CRIP 1-MI

6
0.255 ± 0.04 ohms

* Do not re-use

it is forced in. Note that the turbocharger is integral with the exhaust manifold.

12 Between the turbocharger and the intake manifold, the compressed air passes through an intercooler. This is an air-to-air heat exchanger is mounted next to the radiator, and supplied with cooling air from the front of the vehicle. The purpose of the intercooler is to remove some of the heat gained in being compressed from the intake air. Because cooler air is denser, removal of this heat further increases engine efficiency.


13 Energy for the operation of the turbocharger comes from the exhaust gas. The gas flows through a specially-shaped housing (the turbine housing) and in so doing, spins the turbine wheel. The turbine wheel is attached to a shaft, at the end of which is another vaned wheel known as the compressor wheel. The compressor wheel spins in its own housing, and compresses the intake air on the way to the intake manifold. The turbo shaft is pressure-lubricated by an oil feed pipe from the main oil gallery. The shaft 'floats' on a cushion of oil. A drain pipe returns the oil to the sump. Boost pressure (the pressure in the intake manifold) is limited by a wastegate, which diverts the exhaust gas away from the turbine wheel in response to a pressure-sensitive actuator.

14 If certain sensors fail, and send abnormal signals to the ECM, the ECM has a back-up programme. In this event, the abnormal signals are ignored, and a pre-programmed value is substituted for the sensor signal, allowing the engine to continue running, albeit at reduced efficiency. If the ECM enters its back-up mode, a warning light on the instrument panel will illuminate, and a fault code will be stored in the ECM memory. This fault code can be read using suitable specialist test equipment plugged into the system's diagnostic socket. The diagnostic socket is located beneath the driver's side of the fascia, above the pedals (see illustration).

Warning: It is necessary to take certain precautions when working on the fuel system components, particularly the high-pressure side of the system. Before carrying out any operations on the fuel system, refer to the precautions given in 'Safety first!' at the beginning of this manual, and to any additional warning notes at the start of the relevant Sections. Also refer to the additional information contained in Section 2.

- Do not operate the engine if any of air intake ducts are disconnected or the filter element is removed. Any debris entering the engine will cause severe damage to the turbocharger.

- To prevent damage to the turbocharger, do not race the engine immediately after start-up, especially if it is cold. Allow it to idle smoothly to give the oil a few seconds to circulate around the turbocharger bearings. Always allow the engine to return to idle speed before switching it off – do not blip the throttle and switch off, as this will leave the turbo spinning without lubrication.



1.14 Diagnostic socket (arrowed)


- Observe the recommended intervals for oil and filter changing, and use a reputable oil of the specified quality. Neglect of oil changing, or use of inferior oil, can cause carbon formation on the turbo shaft, leading to subsequent failure.

2 High-pressure diesel injection system – special information

Warnings and precautions

1 It is essential to observe strict precautions when working on the fuel system components, particularly the high pressure side of the system. Before carrying out any operations on the fuel system, refer to the precautions given in *Safety first!* at the beginning of this manual, and to the following additional information.

- Do not carry out any repair work on the high-pressure fuel system unless you are competent to do so, have all the necessary tools and equipment required, and are aware of the safety implications involved.
- Before starting any repair work on the fuel system, wait at least 30 seconds after switching off the engine to allow the fuel circuit to return to atmospheric pressure.
- Never work on the high-pressure fuel system with the engine running.
- Keep well clear of any possible source of fuel leakage, particularly when starting the engine after carrying out repair work. A leak in the system could cause an extremely high-pressure jet of fuel to escape, which could result in severe personal injury.



2.4 Typical plastic plug and cap set for sealing disconnected fuel pipes and components

- Never place your hands or any part of your body near to a leak in the high-pressure fuel system.
- Do not use steam cleaning equipment or compressed air to clean the engine or any of the fuel system components.

Repair procedures and general information

2 Strict cleanliness must be observed at all times when working on any part of the fuel system. This applies to the working area in general, the person doing the work, and the components being worked on.


3 Before working on the fuel system components, they must be thoroughly cleaned with a suitable degreasing fluid. Cleanliness is particularly important when working on the fuel system connections at the following components:

- Fuel filter.
- High-pressure fuel pump.
- Fuel rail.
- Fuel injectors.
- High-pressure fuel pipes.

4 After disconnecting any fuel pipes or components, the open union or orifice must be immediately sealed to prevent the entry of dirt or foreign material. Plastic plugs and caps in various sizes are available in packs from motor factors and accessory outlets, and are particularly suitable for this application (see illustration). Fingers cut from disposable rubber gloves should be used to protect components such as fuel pipes, fuel injectors and wiring connectors, and can be secured in place using elastic bands. Suitable gloves of this type are available at no cost from most petrol station forecourts.

5 Whenever any of the high-pressure fuel pipes are disconnected or removed, a new pipe(s) must be obtained for refitting.

6 The torque wrench settings given in the Specifications must be strictly observed when tightening component mountings and connections. This is particularly important when tightening the high-pressure fuel pipe unions. To enable a torque wrench to be used on the fuel pipe unions, two crow-foot adapters are required. Suitable types are available from motor factors and accessory outlets (see illustration).



2.6 Two crow-foot adapters will be necessary for tightening the fuel pipe unions



3.5 Slacken the retaining clips (arrowed) and disconnect the intake pipes


3 Air cleaner assembly - removal and refitting

Removal

- 1 Remove the front grille (see Chapter 11).
- 2 Remove the right-hand headlight unit as described in Chapter 12.
- 3 Slacken the retaining clip, and disconnect the intake pipe from the top of the air cleaner assembly (see illustration 3.5).
- 4 Apply the handbrake, then jack up the front of the car and support on axle stands (see Jacking and vehicle support). Remove the right-hand front wheel, undo the retaining screws and remove the wheel arch liner.
- 5 From under the vehicle, slacken the retaining clip, and disconnect the intake pipe from the bottom of the air cleaner assembly (see illustration).
- 6 Unscrew the lower mounting nuts (see illustration), and lower the air cleaner assembly from under the inner wing. **Note:** It may be necessary to remove a couple of retaining screws from the right-hand side of the front bumper to allow removal of the air cleaner assembly.
- 7 If required, undo the retaining bolt(s) and remove the bracket for the air intake pipe (see illustration), then withdraw the air intake pipe from across the front of the radiator.



Warning: Do not run the engine with the air cleaner housing and/or ducting removed - the depression at the turbocharger



3.6 Remove the lower mounting nuts (arrowed) and withdraw the air cleaner housing

intake may increase very suddenly if the engine speed is raised above idle.

Refitting

8 Refitting is a reversal of the removal procedure. **Note:** Make sure the peg at the top of the air cleaner assembly, locates in the hole in the inner wing panel.

4 Accelerator pedal/position sensor - removal and refitting

Refer to Chapter 4A, Section 4.

5 Fuel system - priming and bleeding

- 1 After disconnecting the fuel supply system or running out of fuel, it is necessary to prime the fuel system and bleed off any air, which may have entered the system components, as follows.
- 2 Operate the fuel supply pump by switching on the ignition three times for approximately 15 seconds. The engine should now start. If it doesn't, wait a few minutes and repeat the procedure.

6 Fuel gauge sender unit - removal and refitting

On all models, the fuel gauge sender unit is integral with the fuel pump and can only be



3.7 Undo the retaining bolt (arrowed) and the air intake pipe

purchased as a complete assembly. Refer to Chapter 4A, Section 9, for fuel pump removal and refitting.

7 Fuel pump - removal and refitting

The diesel fuel supply pump is located in the same position as the fuel pump on petrol engine models, and the removal and refitting procedures are virtually identical (see illustrations). Refer to Chapter 4A, Section 9, for fuel pump removal and refitting. On completion, bleed the fuel system as described in Section 5.

8 Fuel tank - removal and refitting

Refer to Chapter 4A, Section 12. On completion, bleed the fuel system as described in Section 5.

9 Injection system electrical components - removal and refitting

Airflow meter


- 1 Slacken the retaining clip securing the intake duct to the airflow meter and disconnect the duct.
- 2 Disconnect the airflow meter connector (see illustration).




7.1a Disconnect the wiring connector...



7.1b ... and release the fuel pipes



9.2 Disconnect the airflow meter connector



9.6 Disconnect the charge air hose from the throttle body/housing, and intercooler charge air pipe

- 3 Slacken the retaining clip and remove the airflow meter from the air cleaner housing lid.
- 4 Refitting is a reversal of removal, but ensure that the arrow on the airflow meter points toward the throttle body/housing when fitted.

Throttle body/housing


- 5 Remove the plastic cover from the top of the engine.
- 6 Release the retaining clip and disconnect the charge air hose from the throttle body/housing (see illustration).
- 7 Disconnect the throttle body wiring plug.
- 8 Undo the three retaining bolts and remove the throttle body/housing from the intake manifold. Note the location of any wiring harness support brackets also secured by the retaining bolts.
- 9 Refitting is a reversal of removal, but thoroughly clean the mating faces and use a new gasket/seal. Tighten the retaining bolts to the specified torque.

Crankshaft sensor


- 10 The sensor is located at the rear of the cylinder block, below the starter motor (see illustration). To gain access, firmly apply the handbrake, and then jack up the front of the car and support it securely on axle stands (see *Jacking and vehicle support*).
- 11 Undo the retaining bolts and remove the undershield from beneath the engine/transmission unit.
- 12 Wipe clean the area around the crankshaft sensor then disconnect the wiring connector.
- 13 Slacken and remove the retaining bolt and remove the sensor from the cylinder block. Recover the sealing ring.
- 14 Refitting is the reverse of removal, using a new sealing ring. Tighten the sensor retaining bolt to the specified torque.

Camshaft sensor


- 15 The camshaft sensor is located at the right-hand end of the camshaft housing (see illustration). To gain access, remove the plastic cover from the top of the engine.
- 16 Wipe the area clean around the camshaft sensor, and then disconnect the wiring connector.




9.10 The crankshaft sensor (arrowed) is located beneath the starter motor



9.15 Camshaft sensor location (arrowed)



9.19 The coolant temperature sensor (arrowed) is located at the left-hand end of the cylinder head



9.21 Disconnect the charge air pressure sensor wiring plug (arrowed)

- 17 Slacken and remove the retaining bolt and remove the sensor from the camshaft cover. Recover the sealing ring.
- 18 Refitting is the reverse of removal, using a new sealing ring. Tighten the sensor retaining bolt to the specified torque.

Coolant temperature sensor

- 19 The coolant temperature sensor is located on the thermostat housing on the left-hand end of the cylinder head. Partially drain the cooling system, disconnect the wiring plug and unscrew the sensor (see illustration).
- 20 Refitting is a reversal of removal. Top-up the cooling system as described in Chapter 1B.

Intake air pressure/temperature sensor

- 21 Remove the plastic cover from the top of the engine, then disconnect the wiring connector from the charge pressure sensor located in the centre of the intake manifold (see illustration).
- 22 Slacken and remove the retaining bolt and remove the sensor from the manifold. Recover the sealing ring.
- 23 Refitting is the reverse of removal, using a new sealing ring. Tighten the sensor retaining bolt to the specified torque.


Fuel pressure regulator

- 24 Disconnect the battery negative terminal as described in Chapter 5A.
- 25 Remove the plastic cover over the top of the engine.


- 26 Disconnect the wiring connector from the fuel pressure regulator (see illustration).
- 27 Remove the regulator from the fuel rail by unscrewing the inner nut (nearest the fuel rail) while counter-holding the regulator body with a second spanner. Be prepared for some loss of fuel.
- 28 Refitting is the reverse of removal, tightening the regulator to the specified torque.

Fuel pressure sensor

- 29 Disconnect the battery negative terminal as described in Chapter 5A.
- 30 Remove the plastic cover over the top of the engine.
- 31 Disconnect the wiring connector at the fuel pressure sensor (see illustration).
- 32 Unscrew the sensor and remove it from the fuel rail. Be prepared for some loss of fuel.



9.26 Slide out the yellow locking catch, depress the clip and disconnect the fuel pressure regulator wiring plug



9.31 Disconnect the fuel pressure sensor wiring plug

33 Refitting is the reverse of removal, tightening the sensor to the specified torque.

Electronic control module (ECM)

Note: If a new ECM is to be fitted, this work must be entrusted to a Saab dealer or suitably-equipped specialist, as it is necessary to programme the new ECM after installation. This work requires the use of dedicated Saab diagnostic equipment or a compatible alternative.

34 On all models, the electronic control module (ECM) is located in the same position. Refer to Chapter 4A, Section 14, for the electronic control module removal and refitting.

Turbocharger wastegate solenoid

35 The wastegate (charge pressure) solenoid valve is located at the front of the engine compartment (see illustration).


36 Disconnect the wiring connector and the



10.4a Release the clips and disconnect the upper (arrowed) . . .



10.8 Unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail




9.35 The turbocharger wastegate solenoid is located at the front of the engine compartment

two vacuum hoses from the valve then undo the retaining nuts and remove the valve from its mounting bracket.

37 Refitting is the reverse of removal.

10 High-pressure fuel pump – removal and refitting



Warning: Refer to the information contained in Section 2 before proceeding.


Note: A new fuel pump-to-fuel rail high-pressure fuel pipe will be required for refitting.

Removal


1 Disconnect the battery negative terminal as described in Chapter 5A.

2 Remove the plastic cover over the top of the engine.

3 Remove the timing belt and the high-



10.4b . . . and lower (arrowed) fuel return hoses at the damping chamber



10.9a Unscrew the three retaining nuts (arrowed) . . .

pressure fuel pump sprocket as described in Chapter 2B.

4 Release the retaining clips and disconnect the two fuel return hoses at the damping chamber (see illustrations). Suitably plug or cover the open unions to prevent dirt entry.

5 Disconnect the injector leak-off pipe and fuel return quick-release fitting, then unscrew the two bolts and remove the damping chamber. Suitably plug or cover the open unions to prevent dirt entry.


6 Disconnect the fuel supply hose and release fitting to the high-pressure fuel pump. Suitably plug or cover the open unions to prevent dirt entry (see illustration).

7 Disconnect the wiring connector from the high-pressure fuel pump.


8 Thoroughly clean the fuel pipe unions and fuel pump and fuel rail. Using an open-end spanner, unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

9 Unscrew the three retaining nuts securing the pump from the engine bracket (see illustrations).

Caution: The high-pressure fuel pump is manufactured to extremely close tolerances and must not be dismantled in any way. If parts for the pump are available separately and if the unit is in any way suspect, it must be renewed.



10.6 Insert a generic release tool around the fuel pipe, and push it into the coupling to release the clips and disconnect the pump



10.9b . . . and remove the high-pressure fuel pump from the engine bracket

Refitting

10 Refit the pump to the engine bracket, tighten the retaining bolts to the specified torque.

11 Remove the blanking cap from the pump pipe unions on the pump. Fit a new high-pressure fuel pipe union and screw on the union nut to the pump stage.

12 Using a torque wrench, tighten the fuel pipe adapter, tighten the fuel pipe union to the specified torque. Counter-hold the pump with an open-end spanner, while tightening the union nut.

13 Reconnect the pump and the fuel return hose. Refit the damping chamber retaining bolts and the injector leak-off pipe and fuel return hoses.


15 Refit the high-pressure fuel pipe to the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

16 Reconnect the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

17 Observing the timing belt position in Section 5, then start the engine and let it idle. Check for leaks once again. If a leak is detected, obtain a new fuel pipe.

18 Refit the engine

11 Fuel rail – removal and refitting



Warning: Refer to the information contained in Section 2 before proceeding.

Note: A new fuel pipe will be required for refitting.

Removal

1 Disconnect the battery negative terminal as described in Chapter 5A.

2 Remove the plastic cover over the top of the engine.

3 Thoroughly clean the fuel pipe unions and injector leak-off pipe and fuel return hoses. Using an open-end spanner, unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

4 Using an open-end spanner, unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

5 Using an open-end spanner, unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail. Counter-hold the union on the pump with a second spanner, while unscrewing the union nut (see illustration). Withdraw the high-pressure fuel pipe and plug or cover the open unions to prevent dirt entry.

Refitting

10 Refit the pump to the engine bracket and tighten the retaining bolts to the specified torque.

11 Remove the blanking plugs from the fuel pipe unions on the pump and fuel rail. Locate a new high-pressure fuel pipe over the unions and screw on the union nuts finger-tight at this stage.

12 Using a torque wrench and crow-foot adapter, tighten the fuel pipe union nuts to the specified torque. Counter-hold the unions on the pump with an open-ended spanner, while tightening the union nuts.

13 Reconnect the pump wiring connector and the fuel return hose quick-release fitting.

14 Refit the damping chamber and tighten the retaining bolts securely. Reconnect the injector leak-off pipe, and the two remaining fuel return hoses.

15 Refit the high-pressure fuel pump sprocket and the timing belt as described in Chapter 2B.

16 Reconnect the battery negative terminal as described in Chapter 5A.

17 Observing the precautions listed in Section 2, prime the fuel system as described in Section 5, then start the engine and allow it to idle. Check for leaks at the high-pressure fuel pipe unions with the engine idling. If satisfactory, increase the engine speed to 4000 rpm and check again for leaks. Take the car for a short road test and check for leaks once again on return. If any leaks are detected, obtain and fit a new high-pressure fuel pipe.

18 Refit the engine cover on completion.

11 Fuel rail - removal and refitting

Warning: Refer to the information contained in Section 2 before proceeding.

Note: A complete new set of high-pressure fuel pipes will be required for refitting.


Removal

1 Disconnect the battery negative terminal as described in Chapter 5A.

2 Remove the plastic cover over the top of the engine.

3 Thoroughly clean all the high-pressure fuel pipe unions on the fuel rail, fuel pump and injectors. Using two spanners, hold the unions and unscrew the union nuts securing the high-pressure fuel pipes to the fuel injectors. Unscrew the union nuts securing the high-pressure fuel pipes to the fuel rail, withdraw the pipes and plug or cover the open unions to prevent dirt entry (see illustration).

4 Using an open-ended spanner, unscrew the union nuts securing the high-pressure fuel pipe to the fuel pump and fuel rail (see illustration). Counter-hold the unions on the pump with a second spanner, while unscrewing the union nuts. Withdraw the high-pressure fuel pipe



11.3 Unscrew the union nuts securing the high-pressure fuel pipes to the fuel rail and injectors

and plug or cover the open unions to prevent dirt entry.

5 Disconnect the wiring connectors at the fuel pressure regulator and fuel pressure sensor, then release the clip and disconnect the fuel return hose. Undo the two bolts and remove the fuel rail (see illustrations).

Refitting


6 Refit the fuel rail and tighten the retaining bolts to the specified torque. Reconnect the fuel pressure regulator and fuel pressure sensor wiring connectors, and reconnect the fuel return hose.

7 Working on one fuel injector at a time, remove the blanking plugs from the fuel pipe unions on the fuel rail and the relevant injector. Locate the new high-pressure fuel pipe over the unions and screw on the union nuts finger-tight. Tighten the union nuts to the specified torque using a torque wrench and crow-foot adapter. Counter-hold the union on the injector with an open-ended spanner, while tightening the union nut. Repeat this operation for the remaining three injectors.


8 Similarly, fit the new high-pressure fuel pipe to the fuel pump and fuel rail, and tighten the union nuts to the specified torque. Counter-hold the union on the pump with an open-ended spanner, while tightening the union nut.

9 Reconnect the battery negative terminal as described in Chapter 5A.

10 Observing the precautions listed in Section 2, prime the fuel system as described in Section 5, then start the engine and allow



11.5a Disconnect the fuel return hose...



11.4 Unscrew the union nuts securing the high-pressure fuel pipe to the pump and fuel rail

it to idle. Check for leaks at the high-pressure fuel pipe unions with the engine idling. If satisfactory, increase the engine speed to 4000 rpm and check again for leaks. Take the car for a short road test and check for leaks once again on return. If any leaks are detected, obtain and fit a new high-pressure fuel pipe.

11 Refit the engine cover on completion.

12 Fuel injectors - removal and refitting

Warning: Refer to the information contained in Section 2 before proceeding.

Note 1: A new copper washer, retaining nut and high-pressure fuel pipe will be required for each injector when refitting.


Note 2: The injector is an extremely tight fit in the cylinder head, and it is likely that the special Saab puller (32 025 013) and adapter (32 025 012) or suitable alternatives, will be needed.

Removal


1 Disconnect the battery negative terminal as described in Chapter 5A.

2 Remove the plastic cover over the top of the engine.

3 Release the retaining clip securing the engine breather hose to the breather pipe adjacent to the engine oil dipstick. Undo the two bolts securing the breather pipe to the




11.5b ... then undo the two bolts (arrowed) and remove the fuel rail



[Faint, illegible handwritten text]



THE UNIVERSITY OF CHICAGO



THE UNIVERSITY OF CHICAGO



1. The first part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".



100

THE UNIVERSITY OF CHICAGO

1. *Researcher's name and affiliation*

THE UNIVERSITY OF CHICAGO

management of passing on the knowledge and things that the world brings. Simply going to college and finding out what is out there and then looking for the answers is the traditional way of doing business in the world.

THE UNIVERSITY OF CHICAGO PRESS



2. *Examine the system of land tenure and the system of land use.*




123 Reconnect side mirrors to the
power lock from the cylinder head.

THE NEW YORK PUBLIC LIBRARY
ASTOR LENOX TILDEN FOUNDATION




Female: In some studies, the species have


[illegible]



12.17a Fit the washer . . .



12.17b . . . and the injector clamp bracket retaining nut



12.19 Tighten the fuel pipe union nuts to the specified torque using a torque wrench and crow-foot adapter

extremely close tolerances and must not be dismantled in any way. Do not unscrew the fuel pipe union on the side of the injector, or separate any parts of the injector body. Do not attempt to clean carbon deposits from the injector nozzle or carry out any form of ultrasonic or pressure testing.

12 If the injectors are in a satisfactory condition, plug the fuel pipe union (if not already done) and suitably cover the electrical element and the injector nozzle.

13 Prior to refitting, obtain a new set of copper washers, retaining nuts and high-pressure fuel pipes.

Refitting

14 Thoroughly clean the injector seat in the cylinder head, ensuring all traces of carbon and other deposits are removed.

15 Starting with injector No 4, locate a new copper washer on the base of the injector.

16 Place the injector clamp bracket in the slot on the injector body and refit the injector to the cylinder head.

17 Fit the washer and the injector clamp bracket retaining nut and tighten the nut to the specified torque (see illustrations).

18 Remove the blanking plug from the fuel pipe union on the fuel rail and the injector. Locate the new high-pressure fuel pipe over the unions and screw on the union nuts. Take care not to cross-thread the nuts or strain the fuel pipe as it is fitted.

19 Tighten the fuel pipe union nuts to the specified torque using a torque wrench and crow-foot adapter (see illustration). Counterhold the union on the injector with an open-ended spanner, while tightening the union nut.

20 Repeat this procedure for the remaining injectors.

21 Reconnect the leak-off hose fittings to the injectors by pushing in the locking clip, attaching the fitting, then releasing the locking clip. Ensure that each fitting is securely connected and retained by the clip.

22 Reconnect the wiring connectors to the fuel injectors.

23 Attach the engine breather hose to the breather pipe and secure with the retaining clip. Secure the breather pipe to the cylinder head with the two bolts securely tightened.

24 Reconnect the battery negative terminal as described in Chapter 5A.


25 Observing the precautions listed in Section 2, prime the fuel system as described in Section 5, then start the engine and allow it to idle. Check for leaks at the high-pressure fuel pipe unions with the engine idling. If satisfactory, increase the engine speed to 4000 rpm and check again for leaks. Take the car for a short road test and check for leaks once again on return. If any leaks are detected, obtain and fit a new high-pressure fuel pipe.

26 Refit the engine cover on completion.


13 Intake manifold - removal and refitting

Removal


1 Disconnect the battery negative terminal as described in Chapter 5A.




13.9 Unscrew the nuts and free the wiring harness and coolant pipe from the starter motor bracket



13.10a Undo the two nuts (arrowed) above the vacuum reservoir . . .



13.10b . . . the bolt (arrowed) at the base of the vacuum reservoir . . .



13.10c . . . and the bolts (arrowed) on the right-hand side of the oil separator . . .



13.10d ... then remove the mounting bracket complete with oil separator and vacuum reservoir

base of the vacuum reservoir, and the bolt at the right-hand side of the oil separator. Remove the mounting bracket complete with oil separator and vacuum reservoir (see illustrations).

11 Undo the three bolts, release the hose clip, free the wiring harness and detach the coolant pipe from the intake manifold.

12 Screw two nuts onto the inner high-pressure fuel pump mounting stud. Lock the two nuts together and unscrew the stud from the engine bracket (see illustration).

13 Disconnect the wiring connectors at the throttle body/housing, coolant temperature sensor, intake air sensor, fuel pressure sensor, and fuel pressure control valve.

14 Undo the nine retaining nuts and remove the intake manifold from the cylinder head studs (see illustration). Recover the gasket.

15 With the manifold removed, if required, remove the throttle body/housing with reference to Section 9.


16 The changeover flap actuator drive can be removed by disconnecting the drive motor actuating rod ball socket, and undoing the two stud bolts.

Refitting


17 If removed, refit the throttle body/housing with reference to Section 9, then refit the changeover flap actuator drive.

18 Thoroughly clean the intake manifold and cylinder head mating faces, and then locate a new gasket on the intake manifold flange.

19 Locate the manifold in position and refit the retaining nuts. Diagonally and progressively, tighten the nuts to the specified torque.



14.11 Disconnect the actuating rod ball socket (A), undo the two stud bolts (B) and remove the actuator drive



13.12 Lock two nuts together and unscrew the fuel pump stud from the engine bracket

20 Reconnect the wiring connectors at the throttle body/housing and charge (boost) pressure sensor.

21 Refit the high-pressure fuel pump mounting stud, then remove the two nuts used to remove/refit the stud.

22 Refit the coolant pipe to the manifold, and secure with the three bolts tightened securely. Reconnect the coolant pipe and attach the wiring harness.

23 Refit the oil separator and vacuum reservoir mounting bracket. Refit and tighten the two bolts and two nuts, then reconnect the crankcase breather hoses.

24 Refit the coolant pipe and wiring harness to the starter motor bracket, then refit and tighten the two nuts.

25 Refit the exhaust gas recirculation (EGR) valve as described in Chapter 4C.

26 Refit the high-pressure fuel pump as described in Section 10.

27 Reconnect the battery negative terminal as described in Chapter 5A.

28 Observing the precautions listed in Section 2, prime the fuel system as described in Section 5, then start the engine and allow it to idle. Check for leaks at the high-pressure fuel pipe unions with the engine idling. If satisfactory, increase the engine speed to 4000 rpm and check again for leaks. Take the car for a short road test and check for leaks once again on return. If any leaks are detected, obtain and fit a new high-pressure fuel pipe.

29 Refit the engine cover on completion.

14 Intake manifold changeover flap actuator drive – removal and refitting

Removal


1 Disconnect the battery negative terminal as described in Chapter 5A.

2 Remove the plastic cover over the top of the engine.

3 Remove the high-pressure fuel pump as described in Section 10.

4 Remove the exhaust gas recirculation (EGR) valve as described in Chapter 4C.

5 Drain the cooling system as described in Chapter 1B.



13.14 Intake manifold retaining nuts (arrowed)

6 Release the clips and remove the charge delivery hose from the throttle body/housing.

7 Disconnect the coolant pipe, disconnect the level sensor wiring plug, then remove the coolant reservoir.

8 Disconnect the hose from the throttle body/housing.

9 Undo the nuts securing the coolant pipe to the starter motor bracket, and bend the pipe away slightly (see illustration 13.9).

10 Remove the oil separator and vacuum reservoir mounting bracket by undoing the two nuts above the vacuum reservoir, then at the base of the vacuum reservoir, and the bolt at the right-hand side of the oil separator.

Remove the mounting bracket complete with oil separator and vacuum reservoir (see illustrations 13.10a to 13.10d).

11 Disconnect the drive motor actuating rod ball socket, and undo the 2 stud bolts (see illustration).

12 Withdraw the assembly from the intake manifold and disconnect the wiring plug.

Refitting

13 Refitting is the reverse of removal.

15 Intercooler – removal and refitting

Refer to Chapter 4A, Section 17.

16 Turbocharger – description and precautions

Description

1 The turbocharger increases engine efficiency by raising the pressure in the intake manifold above atmospheric pressure. Instead of air simply being sucked into the cylinder, it is forced in.

2 Energy for the operation of the turbocharger comes from the exhaust gas. The exhaust gas passes through a specially-shaped housing (the turbine housing) and, in so doing, turns a turbine wheel. The turbine wheel is on a shaft, at the end of which is another

wheel known as the compressor wheel. The compressor wheel spins in its own housing, and compresses the intake air on the way to the intake manifold.

3 The turbocharger operates on the principle of variable vane geometry. At low engine speed the vanes close to give less flow cross-section, then as the speed increases the vanes open to give an increased flow cross-section. This helps improve the efficiency of the turbocharger.

4 Boost pressure (the pressure in the intake manifold) is limited by a wastegate, which diverts the exhaust gas away from the turbine wheel in response to a pressure-sensitive actuator.

5 The turbo shaft is pressure-lubricated by an oil feed pipe from the main oil gallery. The shaft 'floats' on a cushion of oil. A drain pipe returns the oil to the sump.

Precautions


- 6 The turbocharger operates at extremely high speeds and temperatures. Certain precautions must be observed, to avoid premature failure of the turbo, or injury to the operator.
 - Do not operate the turbo with any of its parts exposed, or with any of its hoses removed. Foreign objects falling onto the rotating vanes could cause excessive damage, and (if ejected) personal injury.
 - Do not race the engine immediately after start-up, especially if it is cold. Give the oil a few seconds to circulate.
 - Always allow the engine to return to idle speed before switching it off – do not blip the throttle and switch off, as this will leave the turbo spinning without lubrication.
 - Allow the engine to idle for several minutes before switching off after a high-speed run.
 - Observe the recommended intervals for oil and filter changing, and use a reputable oil of the specified quality. Neglect of oil changing, or use of inferior oil, can cause carbon formation on the turbo shaft, leading to subsequent failure.

17 Exhaust manifold and turbocharger – removal and refitting

Note: New manifold retaining nuts, new



17.18 Unscrew the sensor from the catalytic converter




17.7 Undo the oil level dipstick tube bolt (arrowed)

gaskets for all disturbed joints, and new copper washers for the turbocharger oil supply pipe banjo union will be required for refitting.

Removal


- 1 Disconnect the battery negative terminal as described in Chapter 5A.
- 2 Remove the plastic cover from the top of the engine.
- 3 Firmly apply the handbrake, and then jack up the front of the car and support it securely on axle stands (see *Jacking and vehicle support*). Undo the bolts and remove the engine undershield.
- 4 Drain the cooling system as described in Chapter 1B.
- 5 Undo the fasteners and remove the front section of the exhaust pipe.
- 6 Undo the 2 nuts and remove the heat shield over the catalytic converter.
- 7 Undo the bolt securing the oil level dipstick tube (see illustration).
- 8 Release the retaining clip securing the engine breather hose to the breather pipe adjacent to the engine oil dipstick. Undo the two bolts securing the breather pipe to the cylinder head, and disconnect the pipe from the hose.
- 9 Remove the air cleaner assembly and air intake duct as described in Section 3.
- 10 Remove the turbocharger intake hose.
- 11 Remove the turbocharger delivery pipe from the throttle body, and turbocharger.
- 12 Release the clip and disconnect the radiator top hose from the thermostat housing.
- 13 Disconnect the coolant hose between the




17.17 Heat shield retaining nuts and bolts (arrowed)

reservoir and the manifold. Undo the mounting and remove the hose.


- 14 Disconnect the coolant hoses from the coolant pipe at the left-hand end of the engine, then remove the lower coolant hose from the coolant pipe.
- 15 Undo the 3 front bolts and wedge the upper timing cover away from the engine slightly.
- 16 Undo the 3 fasteners and remove the coolant pipe from the front of the engine.
- 17 Remove the heat shield at the front of the turbocharger (see illustration).
- 18 Working underneath the vehicle, unscrew the temperature sensor from the catalytic converter (where fitted) (see illustration).
- 19 Undo the catalytic converter lower mounting bolts, and then bend the lower bracket down a little.
- 20 Undo the upper clamp securing the catalytic converter to the turbocharger, and lower the catalytic converter from place (see illustrations).
- 21 Disconnect the vacuum hose from the turbocharger wastegate actuator.
- 22 Unscrew the four bolts securing the oil return pipe to the turbocharger and cylinder block (see illustration). Remove the pipe and recover the gaskets.
- 23 Unscrew the turbocharger oil supply pipe banjo union from the cylinder block and collect the two copper washers (see illustration).
- 24 Undo the retaining nut and bolt and release the metal EGR pipe clamp from the EGR valve heat exchanger. Separate the pipe from the heat exchanger and recover



17.20a Unscrew the clamp bolt (arrowed) ...



17.20b ... and remove the catalytic converter



17.22 Unscrew the bolts (arrowed) securing the oil return pipe to the turbocharger and cylinder block



17.24 Release the EGR pipe clamp from the heat exchanger, separate the pipe and recover the gasket

the gasket from the pipe connection (see illustration).

25 Unscrew the eight nuts securing the exhaust manifold to the cylinder head (see illustration). Note that new nuts will be required for refitting. Withdraw the manifold and turbocharger assembly from the mounting studs, manipulate it sideways, and remove from under the car. Recover the gasket.


Refitting

26 Refitting is the reverse of removal, noting the following points.


- Ensure all mating surfaces are clean and dry and renew all gaskets, seals and copper washers.



18.5 Spray penetrating oil over the exhaust rubber mounting blocks in the area arrowed



17.23 Unscrew the turbocharger oil supply banjo union (arrowed) and collect the two copper washers



17.25 Exhaust manifold retaining nuts (arrowed)

- Fit the new manifold nuts and tighten them evenly and progressively to the specified torque, working in a diagonal sequence.
- Tighten all other retaining nuts and bolts to the specified torque (where given).
- Refit the exhaust system as described in Section 18.
- On completion refill the cooling system as described in Chapter 1B and, if necessary, top-up the oil level as described in 'Weekly checks'.
- On starting the engine for the first time, allow the engine to idle for a few minutes before increasing the engine speed; this will allow oil to be circulated around the turbocharger bearings.



18.7 Undo the 3 nuts (arrowed) and detach the front exhaust pipe from the catalytic converter

18 Exhaust system – general information, removal and refitting

General information

- Two different exhaust systems are fitted dependent on model, marked as follows. On some models a four-piece system is fitted, comprising a front catalytic converter with silencer. On others, a second catalytic converter/silencer is fitted in place of the first.
- The front pipe is attached to the engine manifold/catalytic converter by a flange joint, secured by nuts. The other exhaust sections are joined by overlap joints, which are secured by clamps, or flange joints secured by nuts. The system is suspended throughout its length by rubber mountings.
- The manufacturers specify that if any of the exhaust sections are separated, the clamps must be renewed. As the clamps are attached to the exhaust sections by means of a weld at manufacture, it will be necessary to use a suitable grinder to remove the weld.


Removal

Complete system


- To remove the system, first jack up the front and rear of the car and support it securely on axle stands. Alternatively, position the car over an inspection pit or on car ramps. The help of an assistant will be needed. Undo the fasteners and remove the engine underbody hangers (see illustration).
- Spray some penetrating oil over the exhaust rubber mounting blocks so that the mounting blocks will slide easily on the exhaust underbody hangers (see illustration).
- Undo the two bolts securing the front support bracket to the transmission bracket sump.
- Undo the three retaining nuts and separate the exhaust front pipe from the exhaust manifold/catalytic converter, taking care to support the flexible section. **Note:** Any movement in excess of 10° can cause permanent damage to the flexible section. Recover the gasket (see illustration). Note that new nuts will be required for refitting.
- Slide the front pipe rubber mounting block as far forward as possible. Move the exhaust system to the rear and disengage the front pipe hangers from the mounting blocks.
- Move the exhaust system forward and disengage the intermediate pipe and tail pipe hangers from the rubber mounting blocks. Lower the system to the ground and slide it out from under the car.

Individual section


- Individual sections of the exhaust system can be removed by slackening the rear clamp and releasing the exhaust from the rubber mountings.



18.17 Pipe to particulate filter in exhaust



18.19 Undo the three retaining nuts – arrowed



18.20 Remove the rear mounting bracket

11 Slacken and remove the nut from the relevant exhaust clamp retaining bolt. Apply liberal amounts of penetrating oil to the joint and tap around the joint and clamp with a hammer to free it. Twist the pipe to be removed in both directions while holding the adjacent pipe. Once the joint is free, pull the pipes apart.

12 Mark the position of the clamp on the pipe, so the new clamp can be fitted in the same position, then grind off the clamp retaining spot weld. Remove the clamp.

Catalytic converter

13 There may be one or two catalytic converters, dependent on model, market, etc. – one fitted between the exhaust manifold and the exhaust front pipe, and a second unit, integral with the exhaust front pipe. Refer to Section 17 for removal and refitting details for the converter fitted between the front pipe and manifold.

14 Where no second catalytic converter is fitted, a particulate filter is installed.

Heat shield(s)

15 The heat shields are secured to the underside of the body by various nuts and threaded caps. Each shield can be removed once the relevant exhaust section has been

removed. If a shield is being removed to gain access to a component located behind it, it may prove sufficient in some cases to remove the retaining nuts/caps, and simply lower the shield, without disturbing the exhaust system. If any of the threaded caps are damaged during removal, a suitable nut and washer can be used when refitting.

Particulate filter

16 Raise the vehicle and support it securely on axle stands (see *Jacking and vehicle support*).

17 Note their fitted positions, and disconnect the exhaust gas temperature sensor pipe(s) from the particulate filter (see *illustration*).

18 If required, unscrew the temperature sensor from the filter.

19 Undo the 3 nuts securing the filter to the front pipe (see *illustration*). Note that new nuts will be required for refitting.

20 Undo the bolts securing the filter rear mounting bracket to the vehicle body (see *illustration*).

21 Slacken the clamp and separate the rear exhaust pipe from the filter.

22 Release the filter from the rubber mountings and withdrawn it from under the vehicle.

23 Upon refitting, apply a little high-temperature anti-seize grease to the temperature sensor threads. Note that if a new particle filter has been fitted, Saab diagnostic equipment must be connected to the vehicle's diagnostic plug to reset adaptation values in the engine management ECM. Entrust this task to a Saab dealer or suitably-equipped specialist.

Refitting

24 Refitting is a reversal of the removal sequence, noting the following points:

- Ensure that all traces of corrosion have been removed from the system joints and renew all disturbed clamps.
- Inspect the rubber mountings for signs of damage or deterioration, and renew as necessary.
- When refitting the front pipe to the manifold/catalytic converter, use a new gasket and new retaining nuts, and tighten the nuts to the specified torque.
- Prior to tightening the exhaust system clamps, ensure that all rubber mountings are correctly located, and that there is adequate clearance between the exhaust system and vehicle underbody. Tighten the clamp bolt retaining nuts securely.